

# BMW MOTORRAD SIZE GUIDE



## MIX AND MATCH/HOW TO WORK OUT YOUR SIZE

Sizes of designs with all-round zips can be combined as follows: (In other size combinations, only the 40 cm connecting zip can be used—not the all-round zip.)

Women Suits	Men Suits
34	46
36	48/50/24/98/102
38/40	52/54/25/26/106/110
42/44	56/58/27/28/114/118
46/48	60/62/29/30
	64/66/31/32

Ask your BMW Motorrad dealer for details on how to combine previous and new rider equipment.

### How to work out your size.

It's very important that your motorcycle suit is a good fit, not least because if it's too tight or too loose, it can affect your concentration. And if you're distracted, this affects your safety on the road.

Jackets and pants also have to sit right on the wearer. Your sleeves and pants legs shouldn't ride up, because if they do, it's not just a safety issue—it also means you're not properly protected against the elements.

That's why the cut of all BMW Motorrad suits is specially designed for motorcycling use, and why they all feature plenty of expandable sections, opportunities for adjustment and other clever details. To make sure your suit is a perfect fit, all of its dimensions have to be exactly right. We know that riders come in many different body shapes, so our suits are available in over 40 different sizes.

To find the one that's right for you, grab your tape measure and follow these simple instructions.

### A Height

Stand barefoot beside a door frame. Place a book on your head, and hold it in position. Mark the position of the book on the door frame and measure from the floor.

### B Chest

Take this measurement while wearing a shirt or a lightweight pullover. Pass the tape measure under your arms and measure around the broadest part of your chest and over the shoulder blades.

### C Waist

Measure around your shirt, just above the top of your pants. Stand in a neutral position and don't hold in your stomach—that way you'll ensure the pants sit comfortably.

### D Hips

Measure around your body, above your pants and the widest point of your hips.

### E Side length

Measure the distance down the outside of your leg, from the waist of your pants to the sole of your foot.

### F Step length

Measure the distance down the inside of your leg, from the crotch seam to the sole of your foot.

### IMPORTANT:

These tables are intended as a guide. They show the body measurements on which the BMW Motorrad rider equipment collection is based.

**BMW Motorrad offers two types of fit according to how each item is used by riders:**

### Comfort fit:

More generous cut offering greater freedom of movement.

### Regular fit:

Closer, anatomical fit.



Size charts

Women	International sizes	Size	Height	Chest	Hips	Waist	Inner leg
Normal	XS	32	168	76	85	62	78
		34	168	80	89	66	78
	S	36	168	84	93	70	78
		38	168	88	96	74	78
	M	40	168	92	99	78	78
		42	168	96	102	82	78
	L	44	168	100	105	87	78
		46	168	104	108	92	78
	XL	48	168	110	113	97	77.5
		50	168	116	118	104	77.5
	2XL	52	168	122	123	111	77
		54	168	128	129	118	77
	Long	72	176	84	93	70	83
		76	176	88	96	74	83
		80	176	92	99	78	83
Short		84	176	96	102	82	83
		88	176	100	105	87	83
		17	160	80	89	66	73
		18	160	84	93	70	73
		19	160	88	96	74	73
		20	160	92	99	78	73
		21	160	96	102	82	73
		22	160	100	105	87	73

Jeans conversion table

Waist in inches	26	27	28	29	30	32	34	36	38	40	42
Waist in cm	67	69	72	74	77	82	87	92	97	102	107
Inner leg in inches	30	32	34	36							
Inner leg in cm	77	82	87	92							

MEN	International sizes	Size	Height	Chest	Hips	Waist	Inner leg
Normal	XS	40	174	80	87	65	80
		42	175	84	90	70	80.5
	S	44	176	88	93	75	81
		46	177	92	96	80	81.5
	M	48	178	96	98	85	82
		50	179	100	101	90	82.5
	L	52	180	104	104	95	83
		54	181	108	107	100	83.5
	XL	56	182	112	110	104	84
		68	183	116	113	109	84.5
	2XL	60	184	120	116	116	85
		62	184	124	119	118	85
	3XL	64	184	128	124	123	84
		66	184	132	129	128	84
	4XL	68	184	136	134	133	83
		70	184	140	139	138	83
Slim fit jackets	XS Slim	40	165	80	87	65	
		42	165	84	90	70	
	S Slim	44	168	88	93	75	
		46	168	92	96	80	
	M Slim	48	170	96	98	85	
		50	170	100	101	90	
Comfort fit jackets	XL comfort						
		68	175	116	113	109	
	2XL comfort	60	178	120	116	116	
		62	178	124	119	118	
	3XL comfort	64	180	128	124	123	
		66	180	132	129	128	
Long		98	187	100	102	89	86.5
		102	188	104	105	94	87
		106	189	108	108	99	87.5
		110	190	112	111	103	88
		114	191	116	114	108	88.5
		118	192	120	117	112	89
Short		24	170	96	97.5	86	78
		25	171	100	100	91	78.5
		26	172	104	103	96	79
		27	173	108	106	100	79.5
		28	174	112	109	105	80
		29	175	116	112	109	80.5
		30	176	120	115	114	81
		31	176	124	118	119	81
		32	176	128	123	124	80